

GYPSUM.

“PLUMA” COLLECTION

Guidelines for the correct installation of polystyrene products

Version: 15/05/2024

- The following general instructions are based on our experience.
- The instructions provided here are for installation on masonry (traditional masonry, dry system such as Aquapanel, Exterior Insulation and Finishing Systems EIFS).
- Before installation, ensure that the substrate is clean, free of dust and grease, solid and suitable for the bonding of products. If this is not the case, arrange the substrate before installation.
- Each individual situation must be carefully assessed by the installer and/or construction management. For any information or needs, please contact the company.
- It is recommended to store the products in a covered, dry place until they are used.


INSTALLATION METHOD (on masonry)

1. Draw the correct positioning of the products to be installed.
The products can be easily cut and fitted on site using a flexible diamond blade or a common straight-tooth hand saw.
2. Spread the cement-based adhesive (of the type commonly used for the Exterior Insulation and Finishing Systems EIFS) on the back of the part using a notched trowel, ensuring that it is evenly distributed over the entire surface. For large products (e.g. 40 × 40 cm eaves), it is recommended to use the polyurethane foam commonly used for the Exterior Insulation and Finishing Systems (EIFS), following the manufacturer's instructions.
3. Position the product by applying light pressure over the entire surface to make it adhere to the substrate. Any unevenness of the substrate can be compensated for by adding glue (maximum 5 millimetres per metre).


4. Apply MS silicone to the head of the installed product: spread a bead of approximately 5 mm both near the finished surface and in the central portion of the section, so that the silicone acts as both adhesive and sealant.
5. Prepare the next product to be installed by applying adhesive as explained in step 2 and MS silicone as explained in step 4. Then proceed with the installation of the product as explained in step 3.
6. Check the correct alignment of the elements on the joints, taking care to correct misalignments, if any. Always leave a joint of approximately 1.5 mm between the products. Wipe off excess MS silicone using a spatula, thus grouting the joint. A few hours after installation, the MS silicone will undoubtedly show shrinkage, which will have to be compensated for with a second grouting, to be made with the same MS silicone.
7. Strictly seal the perimeters of the installed products to prevent water infiltration. Carry out this operation using MS-type silicone, creating a joint between the products and the substrate.
8. The products installed must necessarily be painted after a short time (within 4-5 days after installation) with water-based elastomeric paint. Follow the manufacturer's instructions when applying the paint. Using very dark paints could cause cracking and/or crazing at joints due to thermal expansion.




1



2



3



WARNINGS

GYP SUM S.r.l. is not liable in the event of:

- damage and/or aesthetic variations of the product deriving from improper use of a physical or chemical type;
- damage caused by non-compliance with installation procedures;
- damage caused by neglect and/or other construction site work;
- damage caused by improper storage and handling;
- aesthetic changes resulting from incorrectly executed painting.

GYP SUM S.r.l. reserves the right to amend this document at any time and without prior notice.

GYP SUM S.r.l.

Legal head office: Via Verdi 14 - 24121 Bergamo - Italia

Headquarters: Via C.A. Dalla Chiesa s.n. / Via degli Assini 32 - 24048 Treviolo (BG) - Italia

T. +39 (0)35200085 - info@gypsum-arte.com - www.gypsum-arte.com